



DISTRAN
SWITZERLAND

Ultra Pro X

Ultrasound Imaging
for Gas Leak Detection



APPLICATIONS

- ▶ Predictive maintenance of high-availability plants
- ▶ Urgent leak searches on assets
- ▶ Inspections prior and after planned maintenance activities
- ▶ Routine checks for toxic or explosive gases
- ▶ Cost-effective maintenance of systems using atmospheric gases (compressed air, nitrogen, argon, etc.)

FEATURES

- ▶ Pinpoint leaks of any gas in real-time
- ▶ Inspect from a safe distance of up to 100 meters
- ▶ Take pictures and videos of detected leaks
- ▶ Real-time leak rate estimation to set priorities
- ▶ Integrated reporting system

DESCRIPTION

The ultrasound camera Ultra Pro X uses 124 integrated microphones to locate ultrasound emitted by leaks of all types of gases and vacuum. The sound source location is indicated in real-time on an integrated screen. Pictures and videos can be recorded and integrated in digital reports with DISTRAN Audalytics.

TECHNOLOGY

At the core of Ultra Pro X are the multiple sensing elements included in its head. When a sound wave hits the surface of the device, it reaches the elements at times that differ of less than a millisecond. These little time differences are processed by the device in real-time to display the location of the sound sources.

distran.swiss

SPECIFICATIONS

Detected gases	All compressed gases incl. air, vacuum and steam
Working distance	From: 0.3 - 100 m (12 in - 330 ft) Typical: 1 - 6 m (3 ft - 20 ft)
Lower limit of detection	Quiet environment 2 L/h (0.1 ft ³ /h) Industrial environment 10 L/h (0.4 ft ³ /h)
Pressure difference	Min. 50 mbar (0.7 psi)
Detection method	Acoustic imaging using 124 ultrasound sensors
Acoustic angle of view	180°
Optical angle of view	180°
Resolution optical camera	13 megapixels
Weight	1.5 kg (3.3 lb)
Angular detection accuracy	< 1°
Battery life	5 hours (2.5h x 2 batteries)
Ex-Proof rating	II 3G Ex ic IIC T5 Gc
ATEX & IECEx certified	II 3D Ex ic IIIC T100°C Dc Tamb= -10°C to 40°C FIDI 21 ATEX 0047X IECEx FIDI 23.0008X
Temperature range	-10°C to 50°C (10°F to 122°F)
Ingress protection	IP 54
Integrated LED lights	1400 lumens, dimmable
Screen dimension	5'
Output format	JPEG and AVI
Data export	Audalytics or SD card
Storage	Up to 256 GB
Input methods	Button and touchscreen
Wireless modules	Wifi 802.11 b/g/n



DISTRAN
SWITZERLAND

Distran AG

Heinrichstrasse 200
8005 Zurich, Switzerland
sales@distran.ch
+41 44 271 15 79 (CH)

*Specifications subject to change without notice
Modification not permitted without written
consent from Distran AG
© Distran AG 2024*