

CanNeed-CSS-100B Anti-noise Seam Saw



"CanNeed -CSS-100B Anti-noise seam saw" is provided with an anti-noise design and a special guide for 2- and 3-piece cans (65 mm dia.). Special seam circular saw with double cut for can double seam inspections. The CanNeed -CSS-100B was specially designed for 2 and 3-piece cans. The nitrated blades achieve together with the speed of approx. 1.000 r/min. a very plain cut surface. The seam image on VSM 6A Automatic Seam Computer (Video Seam Monitors), and automatic seam measuring systems gets thereby very clear and improves measurement speed and reliability.

Technical data (changes reserved):

Sample can dia.	: 65mm
Sample type	: 2- and 3-piece cans.
Saw blades	: 80 x 22 x 0,5 mm, (Part No.: HSS-1-80-5)
Speed	: approx. 1.000 r/min.
Power supply	: 220
Power	: 100W
Dimensions	: L380×W240×H200mm
Weight	: 12kg