

CanNeed-CSS-2000 Seam Saw



“CanNeed-CSS-2000 Seam saw” is a special seam circular saw with double cut for double seam inspections. The CanNeed-CSS-2000 was specially designed for 2- and 3-piece cans. The nitrated blades achieve together with the speed of approx. 1.000 r/min. a very plain cut surface. The seam image on CanNeed series Automatic Seam Computer (Video Seam Monitors), and automatic seam measuring systems gets thereby very clear and improves measurement speed and reliability.

Technical data (changes reserved):

Sample can dia. : 45-260 mm (Bigger by order)
Sample type : 2- and 3-piece cans
Saw blades : 80 x 22 x 0,5 mm
Speed : approx. 1.000 r/min.
Power supply : 220 V
Power : 100 W
Dimensions : L370 x W340 x H200 mm
Weight : 20kg

CanNeed CSS-2000A

Seam saw for aerosol cans

